



**NOTES:**

1. FOAM MUST BE CUT OUT IF NECESSARY TO PRESERVE EXISTING DRAIN SIZE.
2. TEMPORARILY COVER DRAIN TO PERFORM FOAM APPLICATION TO ENSURE NO DEBRIS ACCUMULATES IN DRAIN PIPE.
3. SHAPE (GRIND) FOAM AROUND THE BOWL TO MAKE STRAINER FLAT AND IN CONTACT WITH ROOF TO PREVENT PASSAGE OF DEBRIS INTO DRAIN.
4. SLOPE FOAM TO DRAIN TO PREVENT PONDING OF WATER AROUND DRAIN.
5. NAIL THROUGH B.U.R. AREA SURROUNDING DRAINS, WITHIN 6" OF OPENING SPACING NAILS AT 4" O/C.

## ROOF DRAIN

SCALE: NOT TO SCALE

**AMTECH**  
BUILDING SCIENCES, INC.

325 N. Austin Dr. Ste 3  
Chandler, AZ. 85226

☎ 206.718.4883 ☎ 602.910.3003

**CHABOT LAS POSITAS COMMUNITY COLLEGE DISTRICT  
ROOFING AT LAS POSITAS COLLEGE - BLDGS 1700&2200  
3033 COLLIER CANYON RD,  
LIVERMORE, CA.**

DRAWN BY: JG  
SCALE: SEE DWG.  
DATE: AUG. 2011  
DRAWING NUMBER:

D3